

LOCK AND CYLINDER LOCKFITTING INSTRUCTIONS

- 1.- Locate the lock set into the door leaf.
- 2.- Fix the lock set into the hole provided in the leaf with the two retaining screws.
- 3.- Place lock cylinder into the lock set and fix with the retaining screw provided through the face of the lock set (the hole just below the latch)
- 4.- You can regulate the latch length form 0 to 11 mm using grub screw "A"

